USER'S MANUAL



> DLSentinel

DATALOGIC

ORIGINAL INSTRUCTIONS (ref. 2006/42/EC)

See www.patents.datalogic.com for patents list.

Datalogic S.r.l.
Via S. Vitalino 13
40012 Calderara di Reno
Italy

DLSentinel User's Manual
Ed.: 12/2017

© 2017 Datalogic S.p.A. and/or its affiliates ◆ ALL RIGHTS RESERVED. ◆ Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datalogic S.p.A. and/or its affiliates.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

All other trademarks and brands are property of their respective owners.

Datalogic shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material.

01/12/2017

GRAPHIC USER INTERFACE END USER LICENSE AGREEMENT

Whenever YOU download or use the GRAPHIC USER INTERFACE ("GUI") this End User License Agreement ("License") applies to YOU, as final end user, and Licensor. Licensor means Datalogic IP Tech S.r.l. having its registered office at Via San Vitalino 13, 40012 Calderara di Reno, VAT number 03159561202, Italy. This License governs your use of the GUI and related user documentation (the "GUI"). Any Open Source used in a conjunction with the Software is subject to the Open Source licenses available at the following website: http://www.datalogic.com/oss.

By downloading and/or using the GUI, YOU are agreeing to the terms of this License. If YOU don't agree with any of these terms, YOU cannot download or use the GUI.

a. License. Subject to the restrictions this License, Licensor grants YOU a non-exclusive, non-transferable, non-sublicensable, limited license to download, install and use in object code form a single copy of the GUI only on one single computer that YOU own or control, which system requirements shall comply with requirements provided by Licensor, and solely in conjunction with Datalogic Laser Sentinel, defined below, for which it is intended for use.

Title to the licensed GUI shall be and remain with Licensor or the third party from whom Licensor has obtained a license right. This License does not grant to YOU any intellectual property rights on GUI.

b. License Restrictions. YOU may not distribute or make the GUI available over a network where it could be used by multiple devices at the same time, unless otherwise permitted in writing by Licensor.

YOU may not rent, lease, lend, sell, redistribute or sublicense the GUI. YOU may not copy (except as expressly permitted by this), decompile, reverse engineer, disassemble, attempt to derive the source code of, modify or adapt the GUI, in whole or in part, merge the GUI into another program, use the GUI in any manner inconsistent with this License or create derivative works of the GUI, any updates, or any part thereof (except as and only to the extent any foregoing restriction is prohibited by applicable law or to the extent as may be permitted by the licensing terms governing use of this License). YOU may print copies of any user documentation provided in online or electronic form for your personal use. If YOU breach these restrictions, YOU may be subject to prosecution and damages and this License would be immediately terminated.

c. Changes of License. Licensor reserves the right to change all or a part of the License at any time. If Licensor does that, Licensor will post the changed terms at the following website: http://www.datalogic.com. Click on Support > Search by product and enter the Laser Sentinel family name, then select your product from the dropdown list. Click on the Software & Utilities link to download the License.

IF YOU CONTINUE TO USE THE GUI AFTER LICENSOR POST CHANGED TERMS, THAN YOUR USAGE WILL CONSTITUTE YOUR EXPLICIT ACCEPTANCE OF THE CHANGED TERMS.

Licensor is constantly evolving its products. This means Licensor may change or discontinue GUI (and/or our website and any of our other services) without notice or any liability to YOU.

d. Termination. The license is effective until terminated by YOU or Licensor. Your rights under this license will terminate automatically without notice from the Licensor if (i) YOU fail to comply with any term(s) of this license; (ii) YOU delete the GUI; and, to the extent applicable, (iii) YOU use the GUI in connection with a paid service or paid product, the end of the time period specified at time of purchase. Upon termination of the license, YOU shall cease all use of the GUI, and destroy all copies, full or partial, of the GUI.

e. Datalogic Laser Sentinel. The GUI may enable access to Datalogic laser product, Datalogic Laser Sentinel for configuration purposes.

f. Intellectual Property Rights. Except for the rights explicitly granted in this License, Licensor retains and/or control all right, title and interest (including all copyright, patents, trademarks, service marks, trade secrets, or other intellectual property rights) in the GUI, including the copies of the GUI on your computer. YOU acknowledge that the GUI constitutes valuable trade secrets of Licensor or its third party licensors and that the GUI is protected by intellectual property laws and treaties. YOU shall not remove, modify, or take any other action that would obscure any copyright, trademark, patent marking, or other intellectual property notices contained in or on the GUI. Certain of the product and service names used in this License and in the GUI may constitute trademarks of Licensor or third

parties. YOU are not authorized to use any such trademarks, except as it is permitted by applicable laws and agreements. All trademarks are the property of their respective owners.

g. NO WARRANTY. YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF THE GUI IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE GUI IS PROVIDED "AS IS" AND "AS AVAILABLE", WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND APPLICATION PROVIDER HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE GUI AND ANY SERVICES, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, OF SATISFACTORY QUALITY, OF FITNESS FOR A PARTICULAR PURPOSE, OF ACCURACY, OF QUIET ENJOYMENT. LICENSOR DOES NOT WARRANT AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE GUI, THAT THE FUNCTIONS CONTAINED IN, THE GUI WILL MEET YOUR REQUIREMENTS, THAT THE OPERATION OF THE GUI OR SERVICES WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT DEFECTS IN THE GUI WILL BE CORRECTED. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY LICENSOR OR ITS AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY. SHOULD THE GUI PROVE DEFECTIVE, YOU ASSUME THE ENTIRE COST OF ALL NECESSARY REPAIR OR CORRECTION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON APPLICABLE STATUTORY RIGHTS OF A CONSUMER, SO THE ABOVE EXCLUSION AND LIMITATIONS MAY NOT APPLY TO YOU.

h. Limitation of Liability. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL LICENSOR BE LIABLE FOR PERSONAL INJURY, OR ANY DIRECT, INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, LOSS OF DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO YOUR USE OR INABILITY TO USE THE GUI, HOWEVER CAUSED, REGARDLESS OF THE THEORY OF LIABILITY (CONTRACT, TORT OR OTHERWISE) AND EVEN IF APPLICATION PROVIDER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS DO NOT ALLOW THE LIMITATION OF LIABILITY FOR PERSONAL INJURY, OR OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THIS LIMITATION MAY NOT APPLY TO YOU.

i. Export. YOU may not use or otherwise export or re-export the GUI except as authorized by United States law and the laws of the jurisdiction in which the GUI was obtained. In particular, but without limitation, the GUI may not be exported or re-exported (a) into any U.S. embargoed countries or (b) to anyone on the U.S. Treasury Department's list of Specially Designated Nationals or the U.S. Department of Commerce Denied Person's List or Entity List or to anyone towards whom any EU Council Regulation impose restrictive and sanctioned measures. By using the GUI, you represent and warrant that you are not located in any such country or on any such list. YOU also agree that YOU will not use these products for any purposes prohibited by United States and EU law, including, without limitation, the development, design, manufacture or production of nuclear, missiles, or chemical or biological weapons.

l. Open source. Portions of GUI include or operate with Open Source software ("Open Source Software").

Open Source Software is software covered by a publicly available license governed solely under Copyright law, whereas the complete terms and obligations of such license attach to a licensee solely through the act of copying, using and/or distributing the licensed software, such obligations often include one or more of attribution obligations, distribution obligations, copy left obligations, and intellectual property encumbrances. The use of any Open Source Software is subject to the terms and conditions of this License as well as the terms and conditions of the corresponding license of each Open Source Software package. If there is a conflict between the terms and conditions of this License and the terms and conditions of the Open Source Software license, the applicable Open Source Software license will take precedence. Licensor is required to reproduce the software licenses, acknowledgments and copyright notices as provided by the authors and owners, thus, all such information is provided in its native language form, without modification or translation. Please reference and review the above mentioned information to identify which Open Source Software packages have source code provided or available.

m. Confidentiality. YOU acknowledge that GUI content and associated documentation, including the specific design and structure of individual programs, constitute trade secrets and/or copyrighted material of Licensor (and/or its third party's licensors). YOU shall keep the GUI and any related material in strict confidence with all applicable laws. YOU shall not disclose, provide, or otherwise make available the Proprietary Information of

Licensor or its third party licensors to any person and YOU will use such information only for internal business purposes. YOU shall take steps to protect the this information no less securely than if it were your own intellectual property. The provisions of this Proprietary Information Section shall survive and continue for five (5) years after the termination of this License.

n. Applicable Law/Jurisdiction.

n.1 Both parties agree to the application of the laws of the country in which YOU obtained the license to govern, interpret, and enforce all of Your and Licensor's respective rights, duties, and obligations arising from, or relating in any manner to, the subject matter of this License, without regard to conflict of law principles. The United Nations Convention on Contracts for the International Sale of Goods does not apply.

n. 2 All rights, duties, and obligations are subject to the courts of the country in which YOU obtained the license.

For licenses granted to You who operate in the countries specified below, the following terms apply:

For Americas.

This License and the rights of the parties hereunder shall be governed by and construed in accordance with the laws of the State of Oregon U.S.A, without regard to the rules governing conflicts of law. The state or federal courts of the State of Oregon located in either Multnomah or Lane counties shall have exclusive jurisdiction over all matters regarding this License, except that Licensor shall have the right, at its absolute discretion, to initiate proceedings in the courts of any other state, country, or territory in which YOU reside, or in which any of your assets are located. In the event an action is brought to enforce the terms and conditions of this License, the prevailing party shall be entitled to reasonable attorneys' fees, both at trial and on appeal.

Use, duplication, or disclosure of the Software by the U.S. Government is subject to the restrictions for computer software developed at private expense as set forth in the U.S. Federal Acquisition Regulations at FAR 52.227-14(g), or 52.227-19 or in the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013(c)(1)(ii), whichever is applicable.

For Europe, Middle East and Africa

This License and the rights of the parties hereunder shall be governed by and construed in accordance with the laws of Italy, without regard to the rules governing conflicts of law. Italian Court of Bologna shall have exclusive jurisdiction over all matters regarding this License, except that Licensor shall have the right, at its absolute discretion, to initiate proceedings in the courts of any other state, country, or territory in which YOU reside, or in which any of Your assets are located. In the event an action is brought to enforce the terms and conditions of this License, the prevailing party shall be entitled to reasonable attorneys' fees, both at trial and on appeal.

For Asia- Pacific Countries

The validity, interpretation and construction of the License shall be governed by and construed in accordance with Laws of the Republic of Singapore. Parties expressly disclaim the application of the United Nations Convention for International Sale of Goods.

Any dispute arising out of or in connection with this contract, including any question regarding its existence, validity or termination, shall be referred to and finally resolved by arbitration administered by the Singapore International Arbitration Centre ("SIAC") in accordance with the Arbitration Rules of the Singapore International Arbitration Centre ("SIAC Rules") for the time being in force, which rules are deemed to be incorporated by reference in this clause. The seat of the arbitration shall be Singapore.

The number of arbitrators will be three, with each side to the dispute being entitled to appoint one arbitrator. The two arbitrators appointed by the parties will appoint a third arbitrator who will act as chairman of the proceedings. Vacancies in the post of chairman will be filled by the president of the SIAC. Other vacancies will be filled by the respective nominating party. Proceedings will continue from the stage they were at when the vacancy occurred. If one of the parties refuses or otherwise fails to appoint an arbitrator within 30 days of the date the other party appoints its, the first appointed arbitrator will be the sole arbitrator, provided that the arbitrator was validly and properly appointed. All proceedings will be conducted, including all documents presented in such proceedings, in

the English language. The English language version of these terms and conditions prevails over any other language version.

n3. Attorneys' Fees. In the event an action is brought to enforce the terms and conditions of this License, the prevailing party shall be entitled to reasonable attorneys' fees, both at trial and on appeal. Proposals, oral or written, and all other communications between the parties relating to the subject matter of this License. Any terms and conditions of any purchase order or other instrument issued by YOU in connection with this License which are in addition to, inconsistent with or different from the terms and conditions of this License shall be of no force or effect. This License may be modified only by a written instrument duly executed by the parties. Any waiver by either party of any condition, part, term, or provision of this License shall not be construed as a waiver of any other condition, part, term or provision or a waiver of any future event or circumstance. If any provision of this License is held unenforceable, or invalid, the remainder of the License shall continue in full force and effect.

Effective. November 10, 2017.

CONTENTS

REFERENCES 8

1 DLSENTINEL GRAPHIC USER INTERFACE 9
1.1 Program Description 9
1.2 Before using DLSentinel 10
1.3 Installing DLSentinel 10
1.3.1 Minimum System Requirements 10
1.3.2 Program installation 10
1.4 DLSentinel user interface 12
1.4.1 Main menu 13
1.4.2 Toolbar buttons 14
1.4.3 Task selection 15
1.5 Laser sentinel configuration checklist 16

2 LASER SENTINEL CONFIGURATION 17
2.1 New Configuration Selection 17
2.1.1 Save the Configuration 49
2.1.2 Programming 50
2.1.3 Monitoring 52
2.2 Open a Safety System Configuration 53
2.3 Modify Safety System Configuration from a Scanner on the Network 55

3 PROGRAMMING AND MONITORING FUNCTIONS 57
3.1 Monitoring 57
3.2 Programming 60

APPENDIX 63
Access Control 63
DLSentinel Device Discovery 66
Firmware update 69
Using static IP addressing 70

REFERENCES

CONVENTIONS

This manual uses the following conventions:

"DL.Sentinel" refers to the Datalogic User Interface client application running on a PC.

"User" or "Installer" refers to anyone using DLSentinel.

"Device" refers to physical devices used in the safety application: i.e. Laser Sentinel.

"You" refers to the System Administrator or Technical Support person using this manual to install, configure, operate, maintain or troubleshoot a plant equipped with DLSentinel.

REFERENCE DOCUMENTATION

The documentation related to DLSentinel is listed below:

- Device specific Help On Line
- This User's Manual
- Laser Sentinel Instruction Manual

SUPPORT THROUGH THE WEBSITE

Datalogic provides several services as well as technical support through its website. Log on to **www.datalogic.com** and click on the **SUPPORT** link which gives you access to:

- **Downloads** by selecting your product model from the dropdown list in the Search by Product field for specific Data Sheets, Manuals, Software & Utilities and Drawings;
- **Repair Program** for On-Line Return Material Authorizations (RMAs) plus Repair Center contact information;
- **Customer Service** containing details about Maintenance Agreements;
- **Technical Support** through email or phone.

1 DLSENTINEL GRAPHIC USER INTERFACE

1.1 PROGRAM DESCRIPTION

DLSentinel software is a User Interface client application that provides device configuration for the Laser Sentinel series of safety laser scanners. It is installed in and runs on Windows-based PCs (usually laptops), and connection takes place through an Ethernet TCP/IP interface.



Main features

A summary of the DLSentinel main features is listed below:

- Settings for changing the device's password and to manage the network configuration
- User and Session Language configuration in real time
- System configuration
- Report
- Manual

1.2 BEFORE USING DLSENTINEL

In order to employ the device, the DLSentinel GUI is necessary to create a safety configuration, in which the user will insert all the parameters, configure inputs and output and create monitored areas.

1.3 INSTALLING DLSENTINEL

The DLSentinel client application software needs to be installed on your PC to configure the safety laser scanner.

1.3.1 Minimum System Requirements

To ensure proper interfacing with the system, the personal computer must meet the following minimum requirements:

COMPONENT	RECOMMENDED	MINIMUM
Processor(s)	Pentium 4	Pentium 4
Clock frequency	>= 3 GHz	>= 2 GHz
RAM	2 GB	1 GB
Free hard drive space	70 MB	70 MB
Monitor resolution	1280x768	1024x768
Supporting Operating System	Windows XP Windows 7 Windows 8 Windows 10	

Besides the components listed in the table above, your PC must be equipped with the following hardware and software drivers:

- Installed Ethernet network card and installed driver
- One free 100 Mbps Ethernet port

1.3.2 Program installation

DLSentinel is a Datalogic safety laser scanner configuration tool providing several important advantages:

- Intuitive Graphical User Interface for rapid configuration;
- Defined configuration directly stored in the device;
- Discovery and IP address setting features to facilitate remote configuration
- Device Monitoring

To install DLSentinel:

1. On the PC that will be used for configuration, (running Windows XP, 7, 8, or 10), download the DLSentinel.zip file. Extract the file, run the installation program and follow the installation procedure.

2. When the installation is complete the DLSentinel entry is created in the Start > All Programs menu under “Datalogic” as well as a desktop icon. Double-click the desktop icon to run it.



Note: A dedicated computer running DLSentinel must be connected to a safety laser scanner through the Ethernet port to perform the configuration and monitoring features.

1.4 DLSENTINEL USER INTERFACE

After launching DLSentinel in order to configure devices or handle reports, the DLSentinel Task Selection presents the following principal areas:



1. **Main Menu and Toolbar Area** – The DLSentinel main features.

2. **Task Selection Area** – Presents a list of the task that can be performed from DLSentinel. These selections are also available in the File and the Scanner Menus (**Main Menu Area**).

3. **Status Bar** – A reserved area that keeps specific information about the connected device. It displays information on the current network status, the connected device status, the connector and the Application type.

4. **Help Online** – a Help Guide that includes all the info and parameters to create a proper configuration. For the next configuration steps, the help online is available/visible only by clicking on the dedicated button.

1.4.1 Main menu

FILE	
New Configuration	To create a new Device Configuration.
Open Configuration from PC	To open a previously saved Configuration on the local drive.
Read from PC:	
→	**Report** - Shows a Safety System Configuration Report saved on PC.
Save	Saves the current configuration or report on PC.
Exit	To exit the DLSentinel user interface.

SCANNER	
Discovery	Searches for a Device connected to the Network (LAN).
Open Configuration from device	To open a configuration from a Device.
Apply Configuration	To apply a configuration to a connected Device.
Read from device:	
→	**Report** - Shows a Safety System Configuration Report saved on PC.
Settings:	
→	**Change Network Configuration**
→	**Change Access Controls**
→	**Reset Password**
Update Firmware	To update the Firmware file.

OPTIONS	
Change Language	Allows the user to change the display language used for DLSentinel in real time. The selected language will also be used for successive sessions.
Change GUI Log Level	
→	**Verbose**
→	**Information**
→	**Error**
Change GUI Log Options	

HELP	
DLSentinel User Guide	Opens DLSentinel User Manual.
Laser Sentinel Instruction Manual	Shows Laser Sentinel Instruction Manual.
Zip GUI Log	
About	Opens a window that contains DLSentinel release version information.

1.4.2 Toolbar buttons

ICON	DESCRIPTION
	**Getting Started**: allows the user to start a session by clicking on one of the Task Selection options.
	**Save**: saves the current configuration or report session.
	**Configuration Validator:** this tool allows you to check the new configuration in DLSentinel before sending it to the device. By clicking on this option a validation test will be made on the entire configuration in DLSentinel. A pop-up window will appear displaying either a list of configuration errors or validating the configuration.
	**Monitoring**: starts a monitoring session.
	**Help Online**: displays a window that includes the help online guide and it shows the parameters depending on the selected configuration step.


1.4.3 Task selection

The right side of the main window includes the list of the Task selection. The list is explained in the chart below.

ICON	DESCRIPTION
	**New Safety System Configuration (Virtual Scanner)**: to create a new Safety System Configuration on a Virtual Scanner.
	**Open Safety System Configuration from PC**: to open and edit a Configuration saved on PC.
	**Modify Safety System Configuration from a Scanner on the Network**: to edit a Safety System Configuration from a Scanner on the Network.
	**Monitor Safety System**: to enter the monitoring function of a connected Device.
	**Read the Safety System Report from a Scanner on the Network**: to view, print or save a Safety System Configuration Report.
	**Read a Safety System Report from PC**: to view or print a Safety System configuration reports stored on PC.

1.5 LASER SENTINEL CONFIGURATION CHECKLIST

DLSentinel allows creating, testing and validating a device configuration. Complete configuration can only be performed on a connected device (Online).



1. **CONFIGURATION:** create the configuration through Settings, Outputs, Zone Set, Inputs. Detection, Zones.

2. **PROGRAMMING:** upload the configuration and generate the report file.

3. **MONITORING:** test and monitor the device functioning with the new configuration.

4. **PROGRAMMING:** validate the configuration (accept it or reject it).

2 LASER SENTINEL CONFIGURATION

2.1 NEW CONFIGURATION SELECTION

Click on the New Configuration task to create a new configuration and save it on a local PC (for upload to a device at a later time). It is also possible to discover a device and upload the configuration through the Programming menu.




Click on the white right-pointing arrow on the upper right side of the main panel.

1. **Configuration Settings** displays the **Application** type:


   - **Scenario** to select the configuration type (depending on the application).
     → **Expert:** provides the maximum configuration possibilities for the device. It contains the entire set of parameters, regardless of the devices use.

   - **Connector** to select the connector type (depending on the device model and application).
     → **8-pin connection**: The configuration will manage the pins relative to this connector.




It is possible to edit some parameters in **Configuration**, such as:

- **Name**: A name to identify the configuration.
- **Author**: A name to identify the author.
- **Description**: A short text description to identify the configuration.
- **GUI Version**: (Read-only). The software version of DLSentinel.
- **Safety Signature**: (Read-only). This is automatically generated to be a unique identifier that includes the scanner, configuration, creation date-time.
- **Creation Date**: (Read-only). The date and time the configuration was created.
- **Scanner**: A name to identify the scanner.



Note: To proceed with the configuration, click on the white right-pointing arrow on the upper right side on the main panel. To go back to the previous page, click on the white left-pointing arrow.


2. In the **Output Configuration** the following parameters are displayed:



Output Parameters

- **OSSD:** to select how many OSSD pairs use for the configuration. This component is connected to the machine control system and associated with the Safety Zone. If an object is detected in the Safety Zone, the OSSD pair switches to the Off-State effectively shutting down the machine.
    - **1x2** (**One Pair)** All OSSD outputs are managed in pairs, two pins (x2). Pins 5 and 6 are automatically assigned to OSSD 1/1 and 1/2.

- **Warning:** to select how many Warning Zones to use for the configuration. This is the area outside the Safety Zone, where an object can be detected but the device will not switch to the Off-State. It can be used to light a warning lamp or sound a siren. The B5 model can have a maximum of one Warning Zone. The Warning function is assigned to Pin 1.



Output Wires

This parameter group assigns the signals of the output functions to the scanner pins. Each pin is also associated with color-coded cable wiring, according to safety equipment regulations and standards.

- **Pin 1 (White Wire)**

  If a Warning Zone function is selected, this pin must be assigned as the Warning output. Otherwise, it must be assigned here as No Function in order to be used as a Reset, Restart or Area Switch input. See the Zone Set and Input configuration steps.

- **Pin 5 (Gray Wire)**


  This pin is automatically assigned to the safety output OSSD 1/1 (pair 1, output 1).

- **Pin 6 (Pink Wire)**

  This pin is automatically assigned to the safety output OSSD 1/2 (pair 1, output 2).

Note: To proceed with the configuration, click on the white right-pointing arrow on the upper right side on the main panel. To go back to the previous page, click on the white left-pointing arrow.

3. **Zone Sets Configuration** displays the following parameters:



Zone Set Parameters

- **Zone Set No.**: to select how many Zone Sets to use for the configuration (maximum three). The default value is one Zone Set (no Area Switching). By pressing the up arrow more Zone Sets can be added.

- **Input Delay Max [msec]**

  This parameter is valid when there are at least two Zone Sets. It determines the delay to apply between switching from one Zone Set to the next. The input delay allows waiting for the Area Switching inputs to stabilize from their transient states before accepting the Zone Set. Otherwise the activation and deactivation of the inputs could put the device in undesired or invalid and temporary switching zone input combinations and therefore cause the device to enter the fault state.

  The minimum input delay (default) value is 30 msec. It can be increased in 30 msec increments.

- **Zone**

  This parameter group allows editing the Area Switch input combinations depending on how many Zone Sets are selected.

  By selecting more than one Zone Set in the Zone Set No. parameter, a number of Area Switches (AS#) equal to the number of unassigned inputs will appear in the graphic.

  It is possible to set the input switch coding with specific buttons. See the table below.

X	By selecting a Zone Set through the checkbox and clicking on this button, the Zone Set will be removed.
0101 1100 1010	By clicking on this button, the Zone Set Combination will be automatically set.
✓	By clicking this button the created combination will be verified.

Otherwise you can click inside the AS box to manually change its state. To be valid, all Area Switching must differ by two input bit states.

Input Wires
This parameter group assigns the signals of the input functions to the scanner pins. Each pin is also associated with color-coded cable wiring, according to safety equipment regulations and standards.

- **Pin 1 (White Wire)**

  If a Warning Zone function has been selected, this pin will be assigned as the Warning output and is not available for Area Switching. Otherwise, it can be assigned here as an Area Switch input. Selecting No Function here allows it to be used as a Reset or Restart input. See the Input configuration step.

- **Pin 3 (Green Wire)**


  This pin can be assigned to an Area Switch input.

- **Pin 4 (Yellow Wire)**


  This pin can be assigned to an Area Switch input.

Zone Sets configuration example:


- If the configuration includes only one Zone Set, it is not necessary to insert any parameter. Also Pin 3 will be assigned automatically to the **Reset** function and Pin 4 to **No Function**.




- If two Zone Sets are selected, Pins 3 and 4 must be assigned to the **Area Switch** functions (AREA SWITCH 1, AREA SWITCH 2).



- If three Zone Sets are selected (in this case the Warning function is not available), Pins 1, 3 and 4 must be assigned to the **Area Switch** functions (AREA SWITCH 1, AREA SWITCH 2 and AREA SWITCH 3).




If more Zone Sets are selected, make sure to create a valid input coding combination: the zone sets must differ by two input bit states with respect to any other zone set.
For example, the combination shown below is not possible because Zone Set only differs by one input bit state with respect to Zone Set 1 or 2. By clicking on the validation button a pop-up window that shows the coding validation error will be displayed.



Note: To proceed with the configuration, click on the white right-pointing arrow on the upper right side on the main panel. To go back to the previous page, click on the white left-pointing arrow.

4. The **Input Configuration** displays the following parameters:



Input Parameters

- **Restart Mode:** For each Safety Zone you can select the restart mode.

  → **Automatic**: The Laser Sentinel automatically returns the OSSD pair to the On-State after all detected objects are removed from the Safety Zone and the configured Recovery Time elapses.

  → **Manual**: The Laser Sentinel returns the OSSD pair to the On-State after all detected objects are removed from the Safety Zone and a manual Restart switch (push-button) is pressed for at least 500 msec. If the Restart switch is pressed while an object is still inside the Safety Zone, the Laser Sentinel switches to a failure lockout state and must be Reset.

- **Recovery time:** This parameter is only significant for Automatic Restart Mode. The recovery time is the time between the object removal from the Safety Zone and the OSSDs achieving the On-State. Select the time to elapse before the OSSD pair returns to the On-State. The minimum Recovery Time is 80 msec. This can be increased to 100 msec in 1 msec increments.

Input Wires
This parameter group assigns the signals of the input functions to the scanner pins. Each pin is also associated with color-coded cable wiring, according to safety equipment regulations and standards.

- **Pin 1 (White Wire)**

  If this pin has been assigned as the Warning output or as an Area Switch input, it is not available as a manual Restart and/or Reset input.
  If this input is not used, select No Function.

- **Pin 3 (Green Wire)**

  If this pin has been assigned as an Area Switch input, it is not available as a manual Restart and/or Reset input. If this input is not used, select No Function.

- **Pin 4 (Yellow Wire)**

  If this pin has been assigned as an Area Switch input, it is not available as a manual Restart and/or Reset input. If this input is not used, select No Function.



Note: To proceed with the configuration, click on the white right-pointing arrow on the upper right side on the main panel .To go back to the previous page, click on the white left-pointing arrow.

5. The **Detection Configuration** displays the following parameters:

Detection Parameters

- **Number of Scan:** Select the number of scans required to validate detection. This parameter has a direct impact on the **Response Time** which is the time from when an object is detected in the Safety Zone to when the OSSD switches to the OFF-State.
  The Number of Scans determines the Response Time which ranges from 62 to 482 ms in 30 ms increments.

Resolution


- **Detection Capability** The detection capability is the capacity to detect an object of given dimensions within the detection zone. The detection capability for these models is fixed at 70 mm. Objects greater than or equal to this value can be detected both for the Safety and Warning Zones.

- **Dust Filter Level** must be set according to different conditions specific to the application. In general, it is the sensibility to various levels of airborne particles that impact the response of the Laser Sentinel detection.

  → **High** Dust Filter Level is used in dirty environments to filter (ignore) detection of airborne particles from being confused with objects to detect. The Laser Sentinel is less sensitive to dust and therefore avoids shutting down the machinery unnecessarily.

  → **Mid**

  → **Low** Dust Filter Level is used in cleaner environments where airborne particles have little effect on object detection.



Dust Filter Level should be set to the lowest value that still allows the machinery to work without detections due to dust.

Note: In addition to the level of airborne particles in the Laser Sentinel environment, some special lighting conditions also affect the detection sensibility. These conditions are:



- high reflective backgrounds within 2.5 meters of the Safety Zone boundary
- the presence of bright light within +/- 5° of the detection plane.


The additional distance must be included in the Minimum Safety Distance calculations for these cases.

See the graphs in the Laser Sentinel Instruction Manual for these additional distances.




Note: To proceed with the configuration, click on the white right-pointing arrow on the upper right side on the main panel. To go back to the previous page, click on the white left-pointing arrow.


6. In the **Zone Set Configuration**, tools are provided to draw the Safety and Warning Zones. It is possible to select different shapes and different functions to manage the graph.




ICON	DESCRIPTION
	Click this button to draw a circle shaped area by holding pressed the left button of the mouse. Once finished release the left button.




ICON	DESCRIPTION
	Click this button to draw a line shaped area by holding pressed the left button of the mouse. Once finished release the left button.




ICON	DESCRIPTION
	Click this button to free-hand draw the area by holding pressed the left button of the mouse. Once finished release the left button.




ICON	DESCRIPTION
	Click this button to draw an arc shaped area by holding pressed the left button of the mouse. Once finished release the left button.




ICON	DESCRIPTION
	Click this button to draw a rectangle shaped area by holding pressed the left button of the mouse. Once finished release the left button.




ICON	DESCRIPTION
	Click this button to draw a polygon shaped area by holding pressed the left button of the mouse. Once finished release the left button.




ICON	DESCRIPTION
	Click this button to draw constraints by holding pressed the left button of the mouse. Once finished release the left button.




ICON	DESCRIPTION
{x,y}	Click this button to draw an area by inserting the measurements and coordinates




Once the area has been drawn, it is possible to access an edit menu by right-clicking on the selected area. This menu allows to copy, move, edit and delete the area.



ICON	DESCRIPTION
	Click this button to enter the Teach In feature. This function scans and shows the area surrounding the device. It displays a white area which is free from obstacles and therefore can be assigned to a safety or a warning zone. The grey areas are detected obstructions..




ICON	DESCRIPTION
	This function is the Teach In Area Assignment, to assign a zone type to the detected white area. After choosing Teach In, select the checkbox of either the safety zone or warning zone in the left pane and then click this button to assign it.




Teach In and Draw Teach in Zone are available only if the device is online.


ICON	DESCRIPTION
	Click this button to move the graph. Once finished re-click on the button.




ICON	DESCRIPTION
	Click this button to toggle the graph coordinates.




ICON	DESCRIPTION
inch	Click this button to toggle the graph unit of measurement.




ICON	DESCRIPTION
	Click this button to show the area points and edit it. Once finished re-click on the button.




ICON	DESCRIPTION
	Click this button to zoom in the graph. Once finished re-click on the button.




ICON	DESCRIPTION
	Click this button to zoom out the graph. Once finished re-click on the button.




The panel on the left side allows selecting which area handle on the graph and for example to manage them individually.




By clicking on the number (outside the check box), it is possible to highlight a specific area. For example a Safety Zone over a Warning Zone.




By clicking on the check box, it is possible to select and edit a specific area. This parameter allows showing or hiding them together or individually.
By clicking on the name of the area (outside the check box), it is possible to highlight a specific area. For example a Safety Zone over a Warning Zone.






2.1.1 Save the Configuration

Once the configuration is done, it is possible to save it on the PC by clicking on FILE > SAVE.





2.1.2 Programming

Once the configuration is done, it is possible to load it on the device by selecting the function **Programming** on the menu. Follow the steps below:

1. By clicking on Programming, DLSentinel will enter Discovery mode to search for a connected device.

2. The User Interface opens and displays the device with its own default IP Address (192.168.0.10).

3. Double-click on the discovered device to place it in the Device Configuration panel.

4. Click on the white right-pointing arrow on the upper right side on the main panel to proceed.

5. A pop-window will appear suggesting to align the IP Address of the device with the computer LAN. Click OK to proceed and insert the DLSentinel password in order to proceed (default password "**admin**", if not changed).

6. Then change the IP Address parameters in the Network Configuration window to align them with the computer LAN.



Laser Sentinel also reserves the successive IP Address for internal functions.

7. Click OK to accept the new IP Address parameters. The device enters the Offline status, click ok to proceed.


8. DLSentinel will automatically rediscover the device with new IP Address. Double-click on the device to enter Programming.

Now it is possible to conclude the configuration:

1. In **Configuration Upload** click on Load to upload the configuration on the device. To send the configuration to the device you must insert the password (default password "**admin**", if not changed).
   Then test its functioning by entering **Monitoring** (Refer to par. 2.1.3)

2. **Report** file is displayed on the right side of the panel. This document sums up the configuration steps with all the chosen parameters. It is possible to save it as a PDF file and print it.


3. **Validation** after testing the configuration in monitoring and checking the Safety Report, you can accept or reject the configuration.



Note: To proceed with the configuration, click on the white right-pointing arrow on the upper right side on the main panel. To go back to the previous page, click on the white left-pointing arrow.

2.1.3 Monitoring

Once the configuration is uploaded, it is possible to test it by selecting the function **Monitoring** on the menu. Use this function to check the configuration status and if it is properly functioning.



On the panel on the left, the DLSentinel shows the device status (if it is correctly functioning). It is also possible to view some parameters, for example the pin assignment and the recovery time.


Note: To go back to the previous page, click on the white left-pointing arrow.

2.2 OPEN A SAFETY SYSTEM CONFIGURATION


Click on Open a Safety System Configuration from PC task, to open and upload a previously saved configuration on a device.



Select the Configuration File to open.




Once the configuration is opened click on the white right-pointing arrow on the upper right side on the main panel to proceed or to edit the configuration or enter Programming to upload it on the device.




2.3 MODIFY SAFETY SYSTEM CONFIGURATION FROM A SCANNER ON THE NETWORK

Click on Modify a Safety System Configuration from PC task, to edit a configuration on a device on the Network.



By clicking on Modify, DLSentinel will enter Discovery mode to search for a connected device.




If the Laser Sentinel and the PC LAN are not aligned, it will be necessary to set the network configuration settings.

To align the Device and PC LAN IP Addresses follow the steps below:

1. The User Interface opens and displays the device with its own default IP Address (192.168.0.10).

2. Double-click on the discovered device to place it in the Device Configuration panel.



3. Click on the white right-pointing arrow on the upper right side on the main panel to proceed.

4. A pop-window will appear suggesting to align the IP Address of the device with the computer LAN. Click OK to proceed and insert the DLSentinel password in order to proceed (default password “**admin**”, if not changed).

5. Then change the IP Address parameters in the Network Configuration window to align them with the computer LAN.

Laser Sentinel also reserves the successive IP Address for internal functions.

6. Click OK to accept the new IP Address parameters. The device enters the Offline status, click ok to proceed.


7. DLSentinel will automatically rediscover the device with new IP Address. Double-click on the device to modify the configuration.

8. Once the device is selected click on the white right-pointing arrow on the upper right side on the main panel to proceed or to edit the configuration or enter Programming to upload it on the device.

3 PROGRAMMING AND MONITORING FUNCTIONS

3.1 MONITORING

Monitoring is a DLSentinel function that verifies if the created configuration is properly functioning by monitoring the current working area. You have access to this function only by selecting an online device.



The Monitoring function allows checking the following information:

- The OSSDs GO/STOP status.
- The connector pin assignment, colors and functions.
- If the Laser Sentinel detects an object in the Safety and Warning zones.
- Any diagnostic errors that caused the OSSDs Off status.
- The surrounding space detected by the device in real time.
- The switching among the Zone Sets.
- The selected Parameters



Fig. 1 - Monitoring Subpanel

Note: If Monitoring is selected before uploading a new configuration, it displays the previous configuration and the present OSSDs and Warning status.

The table below shows the Monitoring Menu.

ICON	DESCRIPTION
	Click this button to save the Monitoring info in a .txt file.
	Click this button to zoom in the graph. Once finished re-click on the button.
	Click this button to zoom out the graph. Once finished re-click on the button.
	Click this button to toggle the graph unit of measurement.
	Click this button to toggle the graph coordinates.
	Click this button to move the graph. Once finished re-click on the button.

Note: If Errors are detected, the monitoring function displays a popup window with all the detected errors. The device will switch into a Lock status.





Fig. 2 - Lock Status and Device Errors


3.2 PROGRAMMING

Programming is a DLSentinel function that allows uploading a configuration to the device, generating the Safety Report and validating the uploaded configuration (after testing it through the **Monitoring** function, refer to par. 3.1)
The steps below show a proper Programming procedure:

1. Once the configuration has been created or loaded, enter the **Programming** function.
   A **Report** file is generated by DLSentinel.




The Safety Report is a file that sums up all the parameters selected for a configuration and is generated by DLSentinel after uploading a configuration. The Report file is displayed on the right side of the panel. It is possible to save it as a PDF file and print it. Make sure to read the Safety Report and check all the selected parameters




Note: The Safety Report displays the new and the previously used parameters (marked in red).

2. In **Configuration Upload** to upload the configuration from the pc to the device you must insert the password.



3. While uploading the configuration on the device, Laser Sentinel will enter the Off status.



4. Test the configuration functioning by entering **Monitoring**.

5. After testing it and checking the **Report** accept or reject the configuration in **Validation.**

By validating the configuration you take on responsibility for the created configuration accepting the hazard due to configuration errors.


APPENDIX

ACCESS CONTROL


Assign or change passwords

To assign or change the password, the device must be connected (Online).

1. In the DLSentinel Device Selection, click on Scanner and select Settings > Change Access Control.




2. To change or assign the password or access type, you must insert the current one.



3. Enter the new password twice then choose the password type: Write Only (required only when loading the configuration to the device), Read / Write (required when connecting and when loading a configuration to the device) or None (no password required).


4. Then click ok to proceed.




Reset a password

To reset a password, the device must be connected (Online).

1. In the DLSentinel Device Selection window, click on Scanner and select Settings > Reset Password.




2. Contact Datalogic Technical Support and send the serial and the magic number shown. A new password will be communicated to the User.



DLSENTINEL DEVICE DISCOVERY

DLSentinel has a discovery feature to find the connected device.


Click on the Discovery button to search for the connected device.



The User Interface opens and displays the device with its own default IP Address (192.168.0.10).



Double-click on the discovered device to place it in the Device Configuration panel.




From the Scanner menu select Settings > Change Network Configuration. Here the user must insert the DLSentinel password in order to proceed (default password “**admin**”, if not changed).

Then change the IP Address parameters in the Network Configuration window to align them with the computer LAN.

Laser Sentinel also reserves the successive IP Address for internal functions.

Click OK to accept the new IP Address parameters. The device enters the Offline status, click ok to proceed.




DLSentinel will automatically rediscover the device with new IP Address. Double-click on the device to start a new configuration.

FIRMWARE UPDATE

In order to update the firmware, proceed as follows:

1. Start the DLSentinel GUI and select the new configuration task.
2. Enter the Discovery modality and select an online device.
3. Once the device is selected, click **Scanner** on the menu and choose the firmware update option.
4. Insert the device password (default password if not changed by the User) in order to access to the firmware update option.



5. In the Firmware update section (**Package section**), click on ZIP Archive to search and select a previously downloaded new firmware version (from the Datalogic website).
6. Once it is selected the new firmware version. Then click on Load (**Configuration Upload**). During the Firmware Update the device will go offline.
7. When the firmware version is completely loaded, the user enters in the Offline-Test modality to create a configuration and test the new firmware version.
8. If the firmware version is compatible with the device (so that the device configuration is correct with no failures) the user has to click on Accept, otherwise click on Reject (**Validation**).

USING STATIC IP ADDRESSING

It is possible to connect a device to the DLSentinel GUI using the Ethernet TCP/IP interface, the Ethernet IP Addressing parameters must be aligned between the configuration PC and the scanner. The following procedures must be used:

The default Laser Sentinel static assignment Ethernet IP Address is: **192.168.0.10**.


The successive IP Address also will be reserved for internal functions (**192.168.0.10** and **192.168.0.11**)**.**

1. Before changing the Ethernet network settings on the PC running the GUI, close any open applications which use network resources (i.e. Outlook, or Web browser).

2. On the Configuration PC, from the Control Panel>Network and Sharing Center, click on the Local Area Connection link and open the properties window.

3. Select the Internet Protocol Version 4 (TCP/IPv4) item and open the properties window.

4. Set the IP Address fields as follows and click *OK* to save.





DATALOGIC

www.datalogic.com